

# CANON ZOOM

*Most Canon Pro Lenses are 8-pin types, so the customer should check to see if the lens has an 8-pin jack under the servo handle (lens handle). This jack is often covered by a rubber cap from the factory, and in some cases there are multiple jacks with other pin counts, but if the 8-pin jack is present, it should work.*

# CANON FOCUS

**FC-C Works w/ These Known Lenses & all 'Pro-Video Series' (YH / YJ):**

J8X	YH12X
J15X	YH13X
	YH14X
	YH16X
KJ13X	YH17X
KJ20X	YH18X
	YH19X
KH13X	
KH20X	YJ12X
KT14x	YJ13X
KT20X	YJ17X
	YJ18X
PH8X	YJ19X
PH15X	YJ20X

**FC-C WILL NOT WORK** with most 'Broadcast ENG/EFP' or any 'Box-Type Studio/Field' lenses. These are **known lenses that ARE NOT COMPATIBLE**

H9	J9
H15	J11
H20	J15
	J16
HJ9	J17
HJ11	J20
HJ16	J21
HJ17	J22
HJ18	
HJ21	JH18
HJ22	
	KH10
	KH21