

QUICK START GUIDE / VH7 7" HDMI LCD MONITOR

INTRODUCTION

Thank you for purchasing the ikan VH7 LCD Monitor. We know that you will be satisfied with our "V" series monitors. Please visit www.ikancorp.com for more information on our current and future products including our award-winning fluorescent studio lights and light accessories.


PACKAGE INCLUDES

- VH7 LCD Monitor
- AC Power Adapter
- Camera Shoe Mount
- Battery Adapter (check one): [BP2T-S] [BP2T-SU] [BP2T-C] [BP2T-P]
- VGA Cable
- Remote Control
- 2 x Composite Female RCA Cable





MONITOR DIAGRAMS

Front view



Back view



BUTTON FUNCTIONS

- 1 Volume Buttons**
Decreases and increases volume as well as toggle through menu.
- 2 Menu Button**
It is to display brightness, contrast, phase, clock, H position, V position, language, auto, reset, volume, exit.
- 3 Input Button**
Video selection switch AV1, AV2, VGA, HDMI
- 4 ASPECT Selection Button**
Aspect: 16:9, 4:3, Full
- 5 Power Button**
Turns monitor on and off

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.