QUICK START GUIDE / AC107 DV Battery Adapter

ikan

INTRODUCTION

Thank you for purchasing the ikan AC107 DV Battery Adapter. The AC107 is extremely easy to use and will quickly become an integral part of your production kit. For more information on this and many other innovative ikan products, please visit our website: www.ikancorp.com.

MODEL


- ☐ AC107S Sony "L" Series
 ☐ AC107S-U Sony "BP-U" Series
 ☐ AC107C Canon "900" Series
- ☐ AC107P Panasonic "D54" Series

112 129 Checked by

PACKAGE CHECK LIST

- ☐ AC107 DV Battery Adapter
- ☐ Mounting Plate
- ☐ 2 x Phillips Head Screw
- ☐ 1 x M4x.07 x 8mm Metric Socket Head Screw
- ☐ Hex Key

DIAGRAM



CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.